

Remove the canopy posts first, replace it with a M3x6 screw.

將艙罩支柱替換成M3x6螺絲。

Fix and tighten the canopy posts.

將配件艙罩支柱鎖上。

M3x12

