



 Fix the aluminium sheath on the top of the push rod by applying CA glue on it. Install and tighten the ball link for push rod.
使用瞬間膠將拉桿鋁套固定於拉桿前端處，鎖上尾端的尾拉桿頭。

Insert the stainless sliding sleeves on the push rod and adjust its distance as illustrated, then apply CA glue for fixing it.
將不鏽鋼滑套套入尾拉桿內並調整至相同距離後使用瞬間膠黏合。