















請確實依照下方說明組裝,組裝完成後請轉動軸心確認後端 螺絲與固定環無干涉以確保飛行安全。 (如出現干涉請使用兩片螺絲前端的墊片) Please follow instruction below for correct assembly. When assembly is complete, confirm correct operation by moving the shaft axis to confirm the screw & retainer collar is not affecting operation ( if necessary remove screw and add washer for clearance). Insert Retainer collars on both ends of the TT/adapter end then secure with the 2pc set screws (use locitie glue on the screws). 將固定套套入兩端並切齊接合處後 鎖緊止付螺絲(2pcs)。 Tail case 尾殼 4 4 Back End 後端 前端 Front End Remove the screw that is holding the tail boom to the Tail case and add included W2x5.0.5 washer if necessary. Attention! There should be some clearance between this screw and the TT collar. 卸下尾管固定螺絲並於前方 放置內附的W2x5x0.5墊片。 注意螺絲與固定環應有合適 的間隙。